



## THROTTLE BODY GUARD INSTALLATION INSTRUCTIONS

1. Using a 4mm Allen Wrench, remove the two mounting bolts on the oem plastic throttle body guard. (FIG 1)
2. Remove the oem plastic guard.
3. Line up the Aluminum Throttle Body Guard with the same mounting holes as the oem guard. The Enduro Engineering logo should be right side up.
4. Using the same bolts as removed in step 1. Reinstall those bolts and tighten using a 4mm Allen wrench. (FIG 2)
5. Have fun and enjoy your next ride! (FIG 3)



### **WARNING AND DISCLAIMER**

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

### Throttle Body Guard Installation Instructions Part Number 27-1323

*Quality Off-Road Motorcycle Products*  
**Enduro  
Engineering**  
enduroeng.com/517.393.2421/info@enduroeng.com