

1. Using an 8mm T-Handle or socket, remove the 4 OEM skidplate mounting bolts. There is 2 in the front and 1 on each side. **(FIG 1)**
2. Using a 10mm combination wrench, remove the bottom most exhaust mount bolts located near the linkage of the motorcycle. **(FIG 2)**
3. Line up the Enduro Engineering Skidplate to the motorcycle, there is a mounting tab on the skidplate that will line up with the bolt hole from step 2.
4. Thread the provided M6x30 bolt through the skidplate tab and into the exhaust mount hole. Leave this loose for now. **(FIG 3)**
5. Rock the skidplate forward so that it is up against the frame and the four skidplate mounting holes line up with the OEM mount locations. Thread 1 of the provided M6x20 bolts in each of those 4 mounting holes. Leave all bolts until all bolts are started.
6. Starting with the front of the skidplate, use an 8mm T-Handle or socket and tighten the four Skidplate mounting bolts installed in step 5. **(FIG 4)**
7. Reaching in from the backside next to the linkage using either a combination wrench or shallow socket 8mm. Tighten the rear mounting tab bolt. **(FIG 5)**
8. Have fun and enjoy your next ride!



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan Law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

SKIDPLATE INSTALLATION INSTRUCTIONS

Part Number: 24-5119

Quality Off-Road Motorcycle Products

**Enduro
Engineering**

enduroeng.com/517.393.2421/info@enduroeng.com