

SHERCO NUMBER PLATE/ODOMETER BRACKET INSTALLATION

1. Remove Headlight by unhooking rubber straps. Unhook the electrical connector by pressing on the tab as shown. (FIG 1)
2. Using a 3mm Allen wrench, remove the two bolts holding on the Odometer. (FIG 2)
3. Using an 8mm Socket, remove the two bolts holding on the OEM Odometer bracket to the triple clamp. (FIG 3)
4. Line up the new Number plate/ Odometer bracket and mount it back to the triple clamp with the number plate mounting holes facing upwards. Using the same bolts you took out in step 3, attach the number plate/ Odometer bracket. (FIG 4)
5. Using the same bolts you removed in step 2, reattach the Odometer to the number plate/ odometer bracket. (FIG 5)
6. Line up the brake hose guide with the two pre drilled holes on the number plate. The u-shaped piece will be on the outside of the number plate and the flat piece on the back of the number plate. Slide a washer on the brake hose bolt then slide it through the holes on the u-shaped portion, then the number plate, then the flat portion of the brake hose guide. Slide another washer on the bolt, then thread on the provided nut. Using a flat head screw driver and a 7/32 socket or wrench, tighten the nuts down until they are tight. (FIG 6)
7. Line up the guide holes in the bottom of the number plate up with the pins on the front fender. Route the brake hose and odo cable on the outside of the number plate. (FIG 7)
8. Insert the provided M6x16 bolts along with the supplied shoulder spacers in to the number plate/ odometer bracket. The shoulder of the washer should face down in sit inside the number plate holes. Tighten using an 8mm Socket or T-Handle. (FIG 8)



FIG 1



FIG 2



FIG 3



FIG 4



FIG 5



FIG 6



FIG 7



FIG 8

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

Part Number: 25-9018 & 25-9118
Sherco Number Plate/ Odometer Bracket
Installation

Quality Off-Road Motorcycle Products

**Enduro
Engineering**

enduroeng.com/517.393.2421/info@enduroeng.com