




1. Using an 8mm T-Handle or socket, remove the 3 hex bolts in the stater cover that surround the clutch slave cylinder. (FIG 1)
2. Using an 8mm T-Handle or socket, remove the 1 hex bolt on the plastic OEM countershaft sprocket guard. (FIG 2) Then slide the plastic sprocket cover off of the frame post.
3. Using a 10mm T-Handle or socket, remove the bottom subframe bolt. (FIG 3)
4. Using one of the supplied M6x12 hex head bolts, thread it into the clutch slave cylinder where the sprocket guard bolt was removed in step 2. (FIG 4) Tighten to factory spec using an 8mm T-Handle or Socket.
5. Line up the Enduro Engineering Clutch Slave Cylinder Guard to the three mounting holes in the stater cover from the bolts removed in step 1. Thread the provided M6x35 bolts in the top two mounting holes. Thread the provided M6x30 bolt in the bottom mounting hole. (FIG 5) Leave these bolts loose for now.
6. Insert the provided M8x50 bolt through the provided flat washer and then into the subframe, then thread it into the frame and tighten. Now install the thicker of the two provided aluminum spacers onto the threads of the M8x50 bolt that was just installed. Take the provided knock down bar (13-9025-02), line the largest hole with the frame tab and the smaller hole will go onto the M8x50 bolt that was just installed. Be sure that the part number on the knock down bar is facing outward. Now install the thinner provided spacer onto the M8x50 bolt. Thread the provide flange nut on the M8x50 bolt. (FIG 6) Leave loose for now.

TURN PAGE OVER →→→





7. Take the provided M6x12 hex head bolt and thread it through the lower end of the knockdown bar and into the threaded tab of the clutch guard. Leave loose for now. (FIG 7)
8. Using an 8mm T-Handle or socket tighten the 3 bolts on the clutch guard first (FIG 8), then tighten the bolt through the knockdown bar (FIG 9) into the threaded tab of the clutch guard.
9. Using a 10mm T-Handle or socket and a 12mm closed end wrench, tighten the bolt and nut installed in step 6. (FIG 10)
10. Have fun and enjoy your next ride!



WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgement in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI Products will void this limited warranty.) EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing as product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and the Michigan Law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.

INSTALLATION INSTRUCTIONS PART NUMBER 13-9025

Quality Off-Road Motorcycle Products

**Enduro
Engineering**

enduroeng.com//517.393.2421//info@enduroeng.com